


Lesson Microphone Setup Guide


for Swing Catalyst Software

Open Windows Recording Devices Dialog




- 1-2. Start Swing Catalyst and open up screen settings in the main menu.
3. Make note of the microphone name.
4. Click the configure button to open Windows recording devices dialog.

Open properties on recording device



1. Select the microphone device that matches the name in the previous step.
2. Click Properties button.

Open properties on recording device



1. Adjust volume slider.
2. Click Apply to apply changes to microphone volume.
3. Test volume in Swing Catalyst and repeat the above steps to further tweak the volume.